


DisoView E – A Truck Scale in a Regular PC



DisoView E – A Truck Scale in a Regular PC

DisoViewE is programme equipment for IBM-compatible personal computers which enables verifiable depiction of a maximum of 4 weight data sets at the same time from up to 3 physical scales and a composite scale formed from them in regular PCs, without the need to check the PC by ČMI authorities (they are checked only by their own evaluation units, because all calibrating parameters are set in the calibrating field of the evaluation unit).

Basic Information:

- The ability to use evaluation units without a display or to locate units beyond staff range of vision
- The standard PC can be exchanged at any time, because the calibrating parameters are stored outside the PC (this also applies

- to digital scanners)
- The ability to create composite scales in a PC (using single-channel evaluation units)
- The scale window “always on top” (defined minimal window size, cannot be closed)
- Secured data transfer (ability to connect **DisoView E** and scale over a data network)
- Alibi printer is not needed (supported use of verifiable data saving in PC – *DisoSave*)
- Can be used for MS Windows 95/98/Me/NT/2000/XP
- Supports DISOMAT B Plus, DISOMAT F, RTN digi digital weight scanners (in the works).